

# PRIRUČNIK


## MAGDET-301

### MAGDET-301 Installation Guide

Fix a MAGDET-301 sensor firmly on the pole.

The height of the sensor is 0.8m.

Maximum distance between the sensor and the cars 1.8m. Install the sensor as closely as possible.



Power on after fixing the sensor.

The output of the sensor is ON while the calibration is running and will be OFF soon when the sensor is ready.

MAGDET-301 makes a magnetic map at the installed position, so DO NOT MOVE the sensor after power-on. Fix the sensor first, and later power on.

Check the sensor operation with a car.

User can easily check the operation of the sensor by the LED and RELAY on the terminal board.